


INSTRUCTIONS FOR:

'92-'95 EG CIVIC & DC INTEGRA K-SERIES ADAPTER



(This diagram shows the stock OBD1 wire colors and their function, see it in color on Rywire.com)

These wires are meant to be tapped into the wires on your stock OBD1 ECU Plugs.

THIS IS THE COLOR OF THE LOOSE WIRES ON YOUR K-SERIES ADAPTER HARNESS

<u>LOOSE WIRES</u>	<u>FUNCTION</u>
Green/ Yellow	Fuel Pump
Green/Orange	MIL (check engine light)
White/Black	BKSW, Brake Switch
Green/Red	ELD

Yellow/Green - to Coolant temperature sensor for factory water gauge.

THIS IS THE COLOR OF THE WIRES ON YOUR STOCK ECU PLUGS

<u>STOCK POSITION</u>	<u>STOCK COLOR (TO TAP)</u>
A7	Green/Yellow
A13	Green/Orange
D2	Green/White
D10	Green/Red

The solid Green wire is for a optional temperature controlled fan switch. Many Aftermarket ecu's including Hondata can control this function without any need to wire up a remote switch

* ('92-'93') Integra= If chassis has loose White/Green wire, it needs to be wired to the ECU VSS location (B10).